



**CLARUS® CODA**

## Android: CODA Installation

To use CODA with Android, you'll need a USB OTG (On-The-Go) compatible Android device. If you have an Android device that uses USB-C, you can use the USB-C to USB OTG adapter included with CODA. If your Android device uses micro-USB, you'll need to acquire a micro-USB to USB OTG adapter. Whether or not an OTG adapter works is entirely dependent on the design of your Android device. **We can offer no troubleshooting on either of the following solutions other than to mention them as possible options.**

When deciding which OTG adapter(s) to acquire, consider the following options.

### Option 1: 'USB-C to USB' (included) or 'Micro-USB to USB' OTG Adapter

All you need to do is plug CODA into the adapter and attach the adapter to your Android device. The advantage of this option is its simplicity. The drawback is that you can not charge your Android device while listening to audio using CODA.



### Option 2: 'USB-C to USB' or 'Micro-USB to USB' OTG Adapter + Power Cable

With an OTG Adapter + Power Cable, you need to plug CODA into the adapter, plug an external power source into the adapter, and attach the adapter to your Android device. The advantage of this option is that you will not drain your Android device battery while using CODA. This solution is excellent for listeners who travel with their CODA. Please remember, whether or not this solution works depends entirely on the design of your Android device. We can offer no troubleshooting on this solution other than to mention it as a possible option.

